



Transit Curtain Installation Manual V 1



Parts:

- 1 Transit Curtain
- 1 Ceiling Bracket
- 5 Sheet metal screws
- 10 Zip ties 8"
- 2 Zip ties 18"
- 1 Fiberglass rod
- 1 Cable Tie Mount

IMPORTANT:

Each curtain is custom cut for a particular bus model. They will not fit other models – do not attempt.

Read all the instructions through once before starting.



Step 1:

- For the IC and Blue Bird Transit Curtains the ceiling strip bracket is partially bent when you receive it.
- The strip has an adhesive back, remove the red tape, exposing the adhesive.
- Start with the end towards the window butting up to the wiring channel. It has a sticker stating which end goes towards the window.
- Line up the strip so that it is directly above the back edge of the seat. Be sure to make it parallel to the back of the seat.
- The bracket can be 6" in either direction from the top of the seat back to allow for lights or ceiling seams, etc.
- Once held by adhesive, then attach the bracket to the ceiling above the seat back with 5 sheet metal screws.
- The bracket should be flush against the wiring channel.





Step 2:

- Once the top bracket is attached, begin to attach the Transit Curtain using 8" zip ties through the ceiling strip first, then the grommets, **DO NOT TIGHTEN** at this time.



Step 3:

- Attach the cable tie mount to the underside of the wiring channel.
- Attach it to the Transit Curtain using 8" zip tie.
- Once all of them are loosely affixed, then pull the ties tight.





Step 4:

- **Attach the lower end of the transit curtain to the underside of the seat using two 18" zip ties.**
- **There are 6 holes at the bottom near the fiberglass rod. Use 2 that closest fit your circumstances.**
- **The ties can go to the seat post or to the support bar.**

Step 5:

- **Wrap up. Cut all ends of the zip ties. Get some water. It is hot in that bus!**



From your Friends at Bus Safety Solutions

Please Call

if you have any problems with the installation 336-671-0838

