## A/V Controls

### Blank On/Off

Turns the Promethean panel to a black screen without changing sources or turning anything off. Useful for quickly removing the screen from public view. The button turns red when active.

### **Home**

Activates the Promethean panel itself as the display input. This is where the Whiteboard app and other Promethean-specific apps are located. This button is bright when active and dim when inactive.

徻

WALL PLATE

DOC CAM

MUTE

DISPLAY ON/OFF BLANK ON/OFF

(((

Extron

### **Wall Plate**

Activates the two HDMI jacks on the wall. Pressing the button activates the left-hand input and pressing it again activates the right-hand input. This button is bright when active and dim when not.

### Display On/Off

Shuts the Promethean panel off and turns it back on. This is used to shutdown for the night and start up for the day. A red light means the system is off; a dim light means it is on.

## Doc Cam

Sends the picture from the document camea to the Promethean panel for display. This button is brightly lit when active and dimly lit when another source is active.

### Volume Knob

Controls all volume for both the panel and the PC, as well as anything else plugged in to the panel or the wall plate. This sound will all come from the speakers in the ceiling.

### Mute

Shuts off all sound without use of the volume knob. Volume will return to previous levels when the mute button is pressed again. The button turns red when sound is muted.

A/V Controls

### Blank On/Off

Turns the Promethean panel to a black screen without changing sources or turning anything off. Useful for quickly removing the screen from public view. The button turns red when active.

### **Home**

Activates the Promethean panel itself as the display input. This is where the Whiteboard app and other Promethean-specific apps are located. This button is bright when active and dim when inactive.

Â

WALL PLATE

DOC CAM

MUTE

DISPLA

BLANK ON/OFF

((r

Extron

DISPLAY ON/OFF

### **Wall Plate**

Activates the two HDMI jacks on the wall. Pressing the button activates the left-hand input and pressing it again activates the right-hand input. This button is bright when active and dim when not.

### Display On/Off

Shuts the Promethean panel off and turns it back on. This is used to shutdown for the night and start up for the day. A red light means the system is off; a dim light means it is on.

### Volume Knob

Controls all volume for both the panel and the PC, as well as anything else plugged in to the panel or the wall plate. This sound will all come from the speakers in the ceiling.

### Mute

Shuts off all sound without use of the volume knob. Volume will return to previous levels when the mute button is pressed again. The button turns red when sound is muted.

### **Doc Cam**

Sends the picture from the document camea to the Promethean panel for display. This button is brightly lit when active and dimly lit when another source is active.

# **Quick Reference**

\uick Reference